

# How to recovery V9 V9S box via usb device which can not enter menu

Sometime the box don't enter menu or repeat reboot, you can refresh the box via usb device.

Please check the following step:

1. power off box
2. Copy firmware to usb device root dir


Sample:

V1500\_NEWTVPLUS\_VOD\_JS\_MIRA\_USBNIC\_AUTH\_V9\_LED  
F\_SKV9.bin

Rename the file to:

romnew.bin

3. Insert usb device to box
4. Power on box and quickly press the remote key MENU till the tv screen show update information:



5. Witing the box auto reboot.