Wheel TV-Code Setting Setps

1, Upgrade V9/ V9S firmware to latest version which has Wheel TV app.

2, Enter Camds->IPTV as below (press 6666 to show the camds setup)

3, Turn to the Wheel TV as below:

4, Input the User Code like: 3600004405982513 (can get it from dealer)

Type   Wheel TV

User Code   **********

Connect   ←┘

ID:1 Welcome to SoloIPTV .. Successes new register .. Your expire dat
90:23:EC:D4:10:A8

Status: Get Channels Success

Load Usb Config   Delete Current Account   Delete All

5, Click"Connect" and Press "OK" on the remote to get channels.

6, After getting channels successfully, you can Go into the network

app->Wheel TV, you can watch the channels.